Design	Studio	II Coordinates	v 2014

DESIGN STUDIO IICOORDINATES





FLORENTINO

FT-003 Fern

KEY LARGO

KL-027 Sand

ANTIQUE

AQ-002 Carmel

ANTIQUE

AQ-000 Chocolate

JH-010 Snuff

OUTBACK

OB-006 Jet



TECHNICAL INFORMATION

Design Studio II Coordinates

* ACT® Registered Certification Marks

Pattern 54"	Content and Backing	Weight/ Linear Yd	Pattern Repeat	Finish	Abrasion Wyzenbeek	Light ** Fastness	Flammability **	Cleaning Code
ANTIQUE	100% Vinyl Backing: Poly/Cotton Woven	36 oz.	None	None	100,000 Double Rubs	200 hours	See Below	WS
CARESSA FR	100% Vinyl Backing: 100% Brushed Polyester Knit	29 oz.	None	Resilience ^{SR}	650,000 Double Rubs	500 hours	See Below	WS
FLORENTINO	100% Vinyl Backing: 100% Brushed Polyester Knit	28 oz.	None	Resilience ^{SR}	651,000 Double Rubs	1000 hours	See Below	WS
JEKYLL & HYDE^	100% Vinyl Backing: Poly/Cotton Woven	36oz.	None	None	50,000 Double Rubs	200 hours	See Below	WS
KEY LARGO Directional	100% Vinyl Backing: 100% Brushed Polyester Knit	28 oz.	None	Resilience ^{SR}	250,000 Double Rubs	1000 hours	See Below	WS
OUTBACK Directional	100% Vinyl Backing: 100% Brushed Polyester Knit	28 oz.	Non- Matching	Resilience ^{SR}	250,000 Double Rubs	1000 hours	See Below	WS

FLAMMABILITY # *

California Technical Bulletin 117, Section E	Passes	BIFMA Upholstery, Section 4	Passes
NFPA 260 (Equivalent to UFAC) Class 1	Passes	FMVSS 302	Passes
BIFMA CS-191-53, Section 3	Passes	IMO A.652(16) 8.2 & 8.3	Passes
NY & NJ Port Authority – Caressa FR	Passes	ASTM E-84 (Adhered) Class 1 or A – Antique, Caressa FR, Jekyll & Hyde	Passes
Boston Fire Dept. Code (BFD IX01) – Caressa FR	Passes	ASTM E-84 (Adhered) Class 2 or B – Florentino, Key Largo, Outback	Passes

Antique, Caressa FR, Florentino, Jekyll & Hyde, Key Largo and Outback may comply with California Technical Bulletin 133 when combined with appropriate components.

SPECIFIC TREATMENTS

All patterns are sulfide stain resistant.

Resilience SR Resilience Resilien

Anti-Microbial & Anti-Bacterial Protection: Products treated with Resilience^{SR} are engineered to inhibit bacterial growth, as well as fungus, mold and mildew spores, resulting in a more hydienic environment

mildew spores, resulting in a more hygienic environment. **Abrasion Resistance:** Resilience^{SR} provides additional wear properties and surface durability to any vinyl or faux leather, thereby increasing the life of the material. Resilience^{SR} is not visible, and does not affect the hand of the material. Resilience^{SR} is engineered to last, even after repeated cleaning and wear. Specify Resilience^{SR} for the most demanding healthcare and hospitality applications.

For additional specific treatments, please refer to our website or contact customer service.

CARE AND CLEANING INFORMATION

WS: Water/Solvent Cleaner – Spot clean, with a mild solvent, an upholstery shampoo, or the foam from a mild detergent. When using a solvent or dry cleaning product, follow instructions carefully and clean only in a well-ventilated room. Avoid any product that contains carbon tetrachloride or other toxic materials. With either method, pretest a small area before proceeding. Prompt cleaning is always recommended.

RESILIENCE^{SR} CARE AND CLEANING INFORMATION

Step 1: Mild soap and water, then rinse with fresh water and wipe with a clean cloth.

Step 2: Wipe affected area with a soft cloth or soft bristle brush using a non-abrasive cleaner, i.e. Formula 409 or Fantastik. Rinse with fresh water and wipe dry.

Step 3: 10% solution of household bleach and water. Rinse with fresh water and wipe dry.

Step 4: 25% solution of alcohol and water. Rinse with fresh water and wipe dry.

Step 5: 25% solution of lighter fluid or nail polish remover and water. Rinse with fresh water and wipe dry.

Regular Cleaning and Maintenance: Step 1 (Dirt, Dust, Grime)

Oils: Steps 1 & 2 (Organic & Petroleum based)

Food: Steps 1 & 2 (Ketchup, Chocolate, Coffee, Tea, Juice) Healthcare: Steps 1, 2 & 3 (Blood, Urine, Betadine, Disinfectant)

50414

Difficult Stains: Steps 1, 2, 3, 4 & 5 (Eyeshadow/Mascara, Lipstick, Crayon, Grease, Mustard, Ink/Permanent Markers, Paint)

NOTE: The use of commercial vinyl conditioners and protectants is NOT RECOMMENDED.

ADDITIONAL INFORMATION

Additional colors are available. Please refer to our website or contact customer service.

Custom Capabilities: All patterns can be custom colored. Minimum yardage applies.

Memo Samples: Please keep this card intact. Individual memo samples can be ordered on our website or by contacting customer service.

Color matching: Mayer Fabrics always attempts to ship a satisfactory commercial match. Because of industry standard dye lot variation, colors may not match exactly. Specifications: Specifications are correct at the time of printing. Additional specifications are available on our website.

For information or assistance with products or services, call us at 800.428.4415 or refer to our website, www.mayerfabrics.com.

^Jekyll & Hyde is designed to simulate a natural leather that features shade variation and "beauty marks" formed from wrinkles, stretch marks and usage. The effects that will occur with this faux leather product are purposefully intended to mimic those of real leather and are not defects in the product.



GSA Contract #GS-28F-0022P

MAYERFABRICS